


HOSE FITTINGS & ADAPTERS

9/16 MP (13/16 THREAD)

Tool models:


- BA-MP9
- BC-K
- BC-K-P2
- BN33-MP9
- GO-MP9
- RPT-MP9-F
- RPT-MP9-S
- SL-MP9AV9
- SPFR-MP9



HOSE END	LH COLLAR	GLAND NUT	ADAPTER
9/16-18 LH	AF 071-MP9	AF 070-MP9	
M14 LH	AF 071-MPM14L	AF 070-MP9	
M24 Female			GP 255-MP9M24L
1/2 NPT Male			AF 065-MP9P8
3/8 NPT Male			AF 065-MP9P6
9/16-18 Type M			AF 060-MP9
3/4-16 Type M			AF 061-MP9
LANCE END	LH COLLAR	AV GLAND NUT	ADAPTER
9/16-18 LH	AF 071-MP9	AF 072-MP9	
M14 LH	AF 071-MPM14L	AF 072-MP9	
1/2 NPT Male			AF 065-MP9P8
3/8 NPT Male			AF 065-MP9P6

HOSE FITTINGS AND ADAPTERS

9/16 HP (1-1/8 UNF)




Tool models:

- BC-H9-C
- BC-H9LF-C
- BC-H9XXLF-C-TI
- BJV-H9-F
- BJV-H9-S
- GO-H9-C
- UH-40-H9H9-0
- UH-40-H9H9-90
- UH-50-H9H9-0
- UH-50-H9H9-90
- UH-H9G12
- UH-H9G12-90
- UH-H9H6
- UH-H9H6-90
- UHS-H9H9

HOSE END	LH COLLAR	GLAND NUT
9/16-18 LH Male	AF 071-H9	AF 070-H9
M14 LH Male	AF 071-HM14L	AF 070-H9
LANCE END	LH COLLAR	AV GLAND NUT
9/16-18 LH Male	AF 071-H9	AF 072-H9
M14 LH Male	AF 071-HM14L	AF 072-H9

P12 (3/4 NPT)



Tool models:

- BJV-P12-F
- BJV-P12-S
- SG-30-P12-0-18
- SG-30-P12-0-24
- SG-30-P12-90-18
- SG-30-P12-90-24
- SG-40-CCN-P12K-0-2
- SG-40-CCN-P12K-90-2
- SG-50-CCN-P12K-0-2
- SG-50-CCN-P12K-90-2
- SG-CCN-P12K-0
- SG-CCN-P12K-90
- SG-E60-P12K-0-5
- SG-E60-P12K-0-60
- SG-E60-P12K-90-5
- SG-E60-P12K-90-60
- SG-E70-P12K-0-5
- SG-E70-P12K-0-60
- SG-E70-P12K-90-5
- SG-E70-P12K-90-5
- SG-P12K-62-0
- SG-P12P12-62-0
- SG-P12P12-62-90
- TR 230-P12




HOSE END	ADAPTER
1/2 NPT Male	GP 051-P8P12
M24 Female	GP 255-P12M24C
M36 Female	GP 255-P12M36C
LANCE END	ADAPTER
1/2 NPT Male	GP 051-P8P12

HOSE FITTINGS AND ADAPTERS


P8 (1/2 NPT)

Tool models:


- BA-P8-R21
- BA-P8-R31
- BA-P8-R40
- BN33-P8
- RPT-P8-F
- RPT-P8-S
- SG-P8P8-0
- SG-P8P8-90
- SH-P8P8-0
- SH-P8P8-90
- SL-P8P4-0
- SL-P8P4-90
- SPFR-P8-B
- SPFR-P8-S




Adapter




Hose End (Male)




Adapter



Hose End (Female)



Adapter




Rigid Lance End

HOSE END	ADAPTER
1/4 NPT Male	GP 051-P4P8
3/8 NPT Male	GP 051-P6P8
9/16-18 Type M Female	AF 060-P8
3/4-16 Type M Female	AF 061-P8
1-12 Type M Female	AF 063-P8
LANCE END	ADAPTER
1/4 NPT Male	GP 051-P4P8
3/8 NPT Male	GP 051-P6P8

3/4 MP (3/4-14 NPSM)

Tool models:

- BJV-MP12-F
- BJV-MP12-S
- SG-30-MP12-0-18
- SG-30-MP12-0-24
- SG-30-MP12-90-18
- SG-30-MP12-90-24
- SG-40-CCN-MP12K-0-2
- SG-40-CCN-MP12K-90-2
- SG-50-CCN-MP12K-0-2
- SG-50-CCN-MP12K-90-2
- SG-E60-MP12K-0-5
- SG-E60-MP12K-0-60
- SG-E60-MP12K-90-5
- SG-E60-MP12K-90-60
- SG-E70-MP12K-0-5
- SG-E70-MP12K-0-60
- SG-E70-MP12K-90-5
- SG-E70-MP12K-90-60
- SG-MP12-62-90
- SG-MP12AV12-0
- SG-MP12AV12-90
- SG-MP12K-62-0
- TR 230-MP12




HOSE END	LH COLLAR	GLAND NUT	ADAPTER
3/4-16 LH Male	AF 071-MP12	AF 070-MP12	
9/16-18 Type M			AF 060-MP12
3/4-16 Type M			AF 061-MP12
1-12 Type M			AF 063-MP12
1/2 NPT Male			AF 065-MP12P8
3/4 NPT Male			AF 065-MP12P12
LANCE END	LH COLLAR	AV GLAND NUT	ADAPTER
3/4-16 LH	AF 071-MP12	AF 072-MP12	
1/2 NPT Male			AF 065-MP12P8
3/4 NPT Male			AF 065-MP12P12

HOSE FITTINGS AND ADAPTERS

BSPP6 (3/8 BSPP)

Tool models:

- BA-BSPP6-R16-F
- BA-BSPP6-R16-S
- BA-BSPP6-R22-F
- BA-BSPP6-R22-S
- BN24-BSPP6




HOSE END	ADAPTER	COPPER WASHER*
1/4 BSP Female	GP 255-BSPP6-BSPP4C	GP 200-BSPP6
1/2 BSP Female	GP 255-BSPP6-BSPP8C	GP 200-BSPP6
M24 Female	GP 255-BSPP6-M24C	GP 200-BSPP6

*Included with adapter

M24x1.5

Tool models:

- BA-M24-R21
- BA-M24-R31
- BA-M24-R40
- BJ 286-L-M24
- BJ 286-M-M24
- BJ 286-S-M24
- BJ 288-M-M24
- BJ 288-S-M24
- BJV-M24-F
- BJV-M24-S
- RPT-M24-F
- RPT-M24-S
- TR 230-M24



HOSE END	ADAPTER	O-RING*
1/2 BSP Female	GP 255-M240BSPP8C	GP 259
3/4 BSP Female	GP 255-M240BSPP12C	GP 259
M24 Female	GP 255-M240M24C	GP 259
M36 Female	GP 255-M240M36C	GP 259

*Included with adapter